Instruction Manual for
POWER GRIP
(RECHARGEABLE BATTERY)

ACCESSORIES

Never buy batteries again for your GAME BOY® COLOR !

Instruction Manual for
POWER GRIP
(RECHARGEABLE BATTERY)

*Congratulations on your purchase of the **POWER GRIP™**. Before operating, thoroughly familiarise yourself with this manual, so you can understand the functions completely.*

FEATURES:

- Provides up to 15 hours of continuous game play with one charge.
- Unique shape provides better grip and added comfort for extended game play.
- Includes UL approved 120V AC Adapter/ Charger.

USING THE POWER GRIP™:

Attach the **POWER GRIP™** to the GAME BOY® COLOR:

1. Remove the battery cover of the GAME BOY® COLOR.
2. Remove the dry batteries.
3. Insert the **POWER GRIP™** onto the GAME BOY® COLOR hinging it in place like the battery door.

CHARGING THE POWER GRIP™:

- Before using the **POWER GRIP™** for the first time, you must charge it. A complete discharged **POWER GRIP™** takes about 12 to 14 hours to charge fully.
- You can charge the **POWER GRIP™** either attached to the GAME BOY® COLOR or not attached. Make sure that the AC Adapter/ Charger is tightly connected to the **POWER GRIP™** and the mains. After charging completed, disconnect the AC Adapter/ Charger from the **POWER GRIP™** and the mains.

TIP: You can use the **POWER GRIP™** while charging.

IMPORTANT: For best performance, only charge the **POWER GRIP™** when it fully discharged. Charging a not fully discharged **POWER GRIP™** may damage its performance, as well as its life.

SAFETY PRECAUTIONS:

- Do not expose your **POWER GRIP™** to extreme conditions such as high humidity/ rain, high temperatures, direct sunlight, chemicals or dust.
- Adults should supervise children to ensure proper operation of **POWER GRIP™**.
- Take special care in the disposal of your **POWER GRIP™**, using a special facility where available. Do not puncture or burn.
- Use only the supplied AC Adapter/Charger or PL-801 - AC Adapter for use with GAME BOY® COLOR and GAME BOY® POCKET (also sold separately) to charge your **POWER GRIP™**.

IMPORTANT: Unauthorised chargers will invalidate any warranty given for your **POWER GRIP™** and may be dangerous.

TROUBLESHOOTING:

If the GAME BOY® COLOR could not switch on with your **POWER GRIP™** attached:

1. Your **POWER GRIP™** is fully discharged, charge the **POWER GRIP™**.
2. The contacts of the GAME BOY® COLOR and the POWER GRIP™ are dirty, clean them and try again.

PELICAN ACCESSORIES

PELICAN ACCESSORIES

1840 East 27th Street
Vernon, CA 90058 USA
http://www.pelicanacc.com

Power Grip, Pelican and its logo are registered trademarks.
Game Boy® Color is a registered trademark of **Nintendo of America, Inc.**
This product is not designed, manufactured, sponsored or endorsed by **Nintendo of America, Inc.**

MAPL-815/01